


396-100003

TT-001



Installation Instructions:

1. Remove depth gauge wheels and disc's, taking note of shim placement
2. Remove factory seed tube guard remove disc guard bolt on the right side of the row unit (standing behind)
3. Lift TT-001 up into position on row unit
4. Align roll pin holes and install new roll pins (supplied)
5. Re-Install seed tube
6. Re-Install disc openers taking care to get the correct shim placement
7. Re-Install depth gauge wheels