



396-2942Y1 SureFire LiquiShift Mode Selection

The LiquiShift ships with default shifting pressure of 20 PSI and 70 PSI. This can be changed by unplugging the 20-70 PSI jumper and plugging in the desired range. There are 4 settings available:

20-70 PSI (Default), 20-60 PSI, 20-80 PSI, and 15-40 PSI for Electric Tower systems.

The Mode Selection pigtail is a part of the LiquiShift Control Module (shown below).

